

INSTALLATION MANUAL / NÁVOD NA INSTALACI

MPSV 25

CABLE HEATING CIRCUITS / KABELOVÉ TOPNÉ OKRUHY GENERAL TERMS AND CONDITIONS / VŠEOBECNÉ PODMÍNKY

- The heating part of the cable heating circuit may not be shortened or otherwise adjusted in any way. Only the cold connection ends may be shortened, as needed.
- The connector joining the cold connection end and the heating circuit must not be installed in a bend. The heating cables may neither touch nor cross one another. The minimum distance between the cables is 30 mm, and the diameter of a bend must be at least eight times greater than the cable's diameter.
- If the heating or power supply cables are damaged, they must be replaced or repaired by the manufacturer, its service technician or a similarly qualified person in order to prevent a dangerous situation from arising.
- The heating cable must be supplied with electricity by means of a residual current circuit breaker with rated actuating current of $I_{\Delta n} \leq 30mA$. We recommend that each heating unit/circuit be equipped with a separate residual current device.
- The heating cables may be stored at temperatures up to the resistance of the jacket (80°C) and installed at a temperature of greater than - 5. When in use, the cables may not be exposed to temperatures exceeding 80°C.
- The installation must allow disconnecting the cables at both poles.
- Before and after laying the cables, it is necessary to measure the resistance of the heating circuits. The measured values should be equal. Record the measured values in the certificate of warranty. The tolerance of the measured values is $\pm 5-10\%$.
- Before and after laying the cables, it is necessary to measure the insulation resistance between the heating conductor and the protective braiding. This measured value may not be less than 0.5 MΩ. Record the measured values in the certificate of warranty.
- In case of any discrepancies, you should report these immediately to the manufacturer or supplier and discontinue the work completely.
- Before using the heating cable, it is necessary to check whether the data on the label is in accordance with your requested product.
- The supplier must inform other construction suppliers of the place where the heating unit is installed and of the related risks.
- Any manner of use different from those specified in this user guide should be consulted with the manufacturer.
- Topná část kabelového topného okruhu se nesmí krátit, ani jinak upravovat. Krácený dle potřeby mohou být pouze studené připojovací konec.
- Spojka spojující studený konec a topný okruh nesmí být instalována v ohybu. Topné kabely se nesmějí dotýkat, ani křížit, vzdálenost topných kabelů od sebe je min. 30 mm, průměr ohybu kabelu smí být minimálně osminásobek jeho průměru.
- Jestliže je topný kabel nebo napájecí přívod poškozen, musí být nahrazen nebo opraven výrobcem, jeho servisním technikem nebo podobně kvalifikovanou osobou, aby se zabránilo vzniku nebezpečné situace.
- Topný kabel musí být napájen přes proudový chránič se jmenovitým vybavovacím proudem $I_{\Delta n} \leq 30mA$. Doporučujeme každý topný celek/okruh topení vybavit samostatným proudovým chráničem.
- Topné kabely mohou být skladovány do teplotní odolnosti pláště (80°C) a instalovány při teplotě vyšší než -5°C a při provozu nesmí být vystaven teplotám vyšším než 80°C
- Instalace musí umožnit odpojení kabelů v obou pôlech.
- Před pokládkou i po pokládce je nutné provést měření odporu topných okruhu. Naměřené hodnoty se musí shodovat. Naměřené hodnoty zapište do Záručního listu. Tolerance naměřených hodnot $\pm 5 - 10\%$.
- Před pokládkou a po pokládce musí být provedeno měření izolačního odporu mezi topným vodičem a ochranným opletením - naměřená hodnota nesmí být nižší než 0,5 MΩ. Naměřené hodnoty zapište do Záručního listu.
- Jakékoli neshody ihned oznamte výrobci nebo dodavateli a ukončete veškeré práce.
- Před použitím topného kabelu je nutno zkontrolovat štítkové údaje, jestli jsou ve shodě s požadovaným výrobkem.
- Dodavatel musí informovat ostatní dodavatele stavby o umístění topných jednotky a o rizicích z toho vyplynávajících.
- Jiné použití než je v tomto návodu konzultujte s výrobcem.



FENIX

1. Description and connection

- The heating cables should be connected to a 230V, 50Hz electricity network. Degree of protection: IP67.
- The cable jacket is resistant to UV radiation, jacket temperature resistance is 80°C, and it is self-extinguishing.
- The protective braiding is to be connected to the PE protective conductor.

CONSTRUCTION:

- Core: stranded resistance wire
- Insulation: cross-linked polyethylene (XLPE) - 1mm thickness
- Protective braiding: 14 tinned copper wires Ø 0,3mm + AIPET foil
- Jacket: PVC 105°C – thickness 0,8mm

1. Popis a zapojení

- Topné kabely se připojují na soustavu 230V, 50Hz. Krytí IP67.
- Pláští kabelu je odolný proti UV záření, teplotní odolnost pláště 80°C, samozhasívý.
- Ochranné opletení se připojuje na PE vodič.

KONSTRUKCE:

- Jádro: slaněný odporový drát
- Izolace: síťovaný polyetylen (XLPE) - tloušťka 1mm
- Ochranné opletení: 14 Cu drátků Ø 0,3mm pocínovaných + AIPET folie
- Pláští: PVC 105°C (UV odolné) - tloušťka 0,8mm

2. Heating outside areas (anti-freezing protection)

a) Dimensioning


If the heating is intended to be used on open areas with soil as a base and on thermally insulated surfaces, set the flat output to 200-300 W/m². If the heating is intended to be used on surfaces that are not thermally insulated, set the output to 250-350 W/m². The value of the output depends, among other things, on the depth to which the heating system is installed. That means that the closer the installation is to the surface, the lower the output needs to be within the recommended range. If installed into fine washed sand, the installed flat output must not exceed 300 W/m².

2. Vyhřívání venkovních ploch (protinámrazová ochrana)

a) Dimenzování

Plošný příkon dimenzujte na volných prostranstvích jejichž podkladní plocha je zemina a na tepelně izolovaných plochách ve výkonu 200 až 300W/m² a u instalací na tepelně neizolovaných plochách ve výkonu 250 až 350W/m². Velikost výkonu může záviset na hloubce uložení, čím blíže povrchu, tím menší výkon z doporučeného intervalu. V případě montáže do jemného plaveného píska nesmí instalovaný plošný výkon přesahovat 300W/m².

Installing into concrete / Instalace do betonu



1)Tiles (concrete) / Dlažba (beton)

2)Ecofloor heating cable / Topný kabel Ecofloor

3)Reinforcing steel grid / Armovací ocelová síť (KARI)

4)Concrete layer / Betonová vrstva

5)Base (gravel, 150-300mm) / Podklad (štěrk 150-300mm)

b) Installing into concrete

Procedure

- Create a compact underlying layer of gravel 150–300 mm thick. This can be regarded as the thermal insulation.
- Place the heating cable in an open-looping pattern on the reinforcing grid and fix it with fastening strips. The heating cable must not be too tightly affixed or it could be damaged due to the thermal expansion of the concrete.
- Place the reinforcing grid in the middle, and at maximum 2/3 down into the concrete layer.
- Measure the resistance of the heating circuit and the insulation resistance and record the measured values in the certificate of warranty.
- Draw the scheme of the heating cable layout in the certificate of warranty.
- Cover the cable with a concrete layer. The concrete layer must be monolithic so that individual layers do not separate due to thermal stress.
- Measure the resistance of the heating circuit and the insulation resistance again and record the measured values in the certificate of warranty.
- The concrete mixtures must contain ingredients protecting it against external effects.

c) Regulation

- To avoid exceeding the upper limit of the cable's thermal resistance, which could occur due to improper use (such as by operating the heating system in the summer months) and in respect of economic operation, the installation must be equipped with one of FENIX's available thermostats, such as EBERLE EM 524 87 + moisture probe ESF 524 001 + thermal sensor TFF 524 002.

b) Montáž do betonu

Postup

- Vytvořte z hutněnou podkladovou vrstvu štěrku 150 - 300mm, vrstvu štěrku můžete považovat za tepelnou izolaci.
- Na armovací síť rozvíjte topný kabel ve tvaru meandru a fixujte stahovací páskou. Topný kabel nesmí být příliš uťažen, aby nedošlo vlivem teplotní roztažnosti betonu k poškození kabelu.
- Armovací síť umístěte do středu, maximálně však do 2/3 betonové vrstvy.
- Proveďte proměření odporu topného okruhu a izolačního odporu, hodnotu zapište do Záručního listu.
- Zakreslete do záručního listu rozložení kabelu.
- Kabel zalijte vrstvou betonu. Betonová vrstva musí být monolitická aby vlivem teplotního namáhaní nedošlo k odtržení jednotlivých vrstev.
- Opětovně proveďte proměření odporu topného okruhu a izolačního odporu, hodnotu zapište do Záručního listu.
- Betonové směsi musí osahovat příměsi chránící směs před vnějšími vlivy.

c) Regulace

- Z hlediska nepřekročení horní meze teplotní odolnosti kabelu, k němuž může dojít při nesprávném použití (provoz v letních měsících) a z hlediska úspornosti provozu je potřeba instalaci vybavit regulátorem z aktuální nabídky firmy FENIX, například EBERLE EM 524 87 + vlhkostní sonda ESF 524 001 + teplotní čidlo TFF 524 002.

3. Warranty, claims

The supplier of the ECOFLOOR cable circuits provides a warranty period of 24 months for the product's functionality, beginning from the date of its installation that is confirmed in the certificate of warranty (installation must be made at latest within 6 months from the date of purchase), provided that:

- a certificate of warranty and proof of purchase are submitted,
- the procedure described in this user guide has been followed,
- data on laying and connecting the cable in the floor and the resulting measured values of the insulation resistance of the heating cable are provided, and
- the procedure for applying the sealing cement specified by its producer has been followed.

Claims may be made in writing at the company that performed the installation or directly to the manufacturer.

Provided that the aforementioned conditions were met and the warranty period has expired, the conditions under the claims procedure, clause 5, apply for an additional period of 3 years.

The claims procedure also is available at the website <http://www.fenixgroup.cz>.

3. Záruka, reklamace

Dodavatel kabelových okruhů ECOFLOOR poskytuje záruku na její funkčnost po dobu 24 měsíců ode dne instalace potvrzené na záručním listě (instalace musí být provedena maximálně 6 měsíců od data prodeje) pokud je:

- doložen záruční list a doklad o zakoupení,
- dodržen postup dle tohoto návodu,
- doloženy údaje o skladbě kabelu v podlaze, zapojení a výsledcích měření izolačního odporu topněho kabelu,
- dodržen návod výrobce pro aplikaci tmelů.

Reklamace se uplatňuje písemně u firmy, která provedla instalaci, případně přímo u výrobce. Při dodržení výše uvedených podmínek a po uplynutí záruční doby platí po dobu dalších 3 let podmínky dle reklamačního řádu, bod č. 5.

Reklamační řád je také na <http://www.fenixgroup.cz>



Fenix Trading s.r.o.

Slezská 2, 790 01 Jeseník

tel.: +420 584 495 304, fax: +420 584 495 303

e-mail: fenix@fenixgroup.cz • <http://www.fenixgroup.cz>